



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2265029 Smash Lady**

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
body lenght CB	62	64	66	68	70	72	74		
1/2 chest	45	47	79	51	53	56	59		
Sleevelenght	17	17,5	18	18,5	19	19,5	20		

All measurements are indicative with minimum tolerance of 1 cm

Printer
ACTIVE WEAR

SIZE CHART



Brand: PRINTER ACTIVE WEAR

Style: 2261509 TWOHAND LADY

	XS	S	M	L	XL	XXL	3XL
A) body length from shoulder point	63	65	67	69	71	73	75
B) 1/2 chest width	43	46	49	52	56	60	64
c) sleeve length	62	63	64	65	66	67	68

All measurements are indicative with minimum tolerance of 1 cm



Brand: PRINTER ACTIVE WEAR

Style: 2261508 TWOHAND

	S	M	L	XL	XXL	3XL	4XL	5XL
A) body length from shoulder point	70	72	74	76	78	80	82	84
B) 1/2 chest width	51	54	57	60	64	68	72	76
c) sleeve length	67	68	69	70	71	72	73	74

All measurements are indicative with minimum tolerance of 1 cm

Printer
ACTIVE WEAR

SIZE CHART




Brand: PRINTER ACTIVE WEAR

Style: 2261507 SIDEFLIP LADY

	XS	S	M	L	XL	XXL	3XL
A) body length from shoulder point	63	65	67	69	71	73	75
B) 1/2 chest width	44	47	50	53	57	61	65

All measurements are indicative with minimum tolerance of 1 cm




Note: The measurements on this chart shall be adapted on flat garments.

134026 EATON	S	M	L	XL	XXL	3XL	4XL
A Body length from inner shoulder	70	72	74	76	79	82	85
B ½ Chest	50	53	56	60	65	70	75
C ½ Bottom	48,5	51,5	54,5	58,5	63,5	68,5	73,5
D Shoulder width	44	46	48	50	52	54	56
E Sleeve length	19	20	21	22	23	24	25

Note: The measurements on this chart shall be adapted on flat garments.

134027 EATON LADY	S/36	M/38	L/40	XL/42	XXL/44
A Body length from inner shoulder	62	64	66	68	70
B ½ Chest	46	48	50	53	56
C ½ Waist	42	44	46	49	52
D ½ Bottom	46	48	50	53	56
E Shoulder width	39	40	41	42	43
F Sleeve length	13,5	14	14,5	15	15,5



Note: The measurements on this chart shall be adapted on flat garments.


134026 EATON	S	M	L	XL	XXL	3XL	4XL
A Body length from inner shoulder	70	72	74	76	79	82	85
B ½ Chest	50	53	56	60	65	70	75
C ½ Bottom	48,5	51,5	54,5	58,5	63,5	68,5	73,5
D Shoulder width	44	46	48	50	52	54	56
E Sleeve length	19	20	21	22	23	24	25

Note: The measurements on this chart shall be adapted on flat garments.

134027 EATON LADY	S/36	M/38	L/40	XL/42	XXL/44
A Body length from inner shoulder	62	64	66	68	70
B ½ Chest	46	48	50	53	56
C ½ Waist	42	44	46	49	52
D ½ Bottom	46	48	50	53	56
E Shoulder width	39	40	41	42	43
F Sleeve length	13,5	14	14,5	15	15,5

Printer
ACTIVE WEAR

SIZE CHART



Brand: PRINTER ACTIVE WEAR


Style: 2264023 RUN

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
A) body length	68	70	72	74	76	78	80	82	84
B) 1/2 Chest width	46	49	52	55	59	63	67	71	75
C) Sleeve length	16	18	20	21	22	23	24	24,5	25

All measurements are indicative with minimum tolerance of 1 cm

Printer
ACTIVE WEAR

SIZE CHART



Brand: PRINTER ACTIVE WEAR
Style: 2264026 RUN LADY

	XS	S	M	L	XL	XXL	3XL
A) body length	62	63,5	65	67	69	71	73
B) 1/2 chest width	42	45	48	51	55	59	63
C) Sleeve length	16	16,5	17	17,5	18	18,5	19

All measurements are indicative with minimum tolerance of 1 cm



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2265028 Smash**

	S	M	L	XL	XXL	3XL	4XL	5XL	6XL
body length CB	70	72	74	76	78	80	82	84	86
1/2 chest	50	53	56	60	64	68	72	76	80
Sleevelenght	19	20	21	22	23	24	25	26	26

All measurements are indicative with minimum tolerance of 1 cm



SIZE CHART



Brand: PRINTER ACTIVE WEAR

Style: 2261506 SIDEFLIP

	S	M	L	XL	XXL	3XL	4XL	5XL
A) body length from shoulder point	70	72	74	76	78	81	84	87
B) 1/2 chest width	52	55	58	61	65	69	73	77

All measurements are indicative with minimum tolerance of 1 cm